

Instruction Manual

POWER PANEL plus M



N° 00760220 or 00760221

Used in conjunction with the standard sets TESA Micro-Hite plus M 350 00730063 600 00730064 900 00730065



Contents		Page
1	Main features	5
2	Keyboard	6
3	Starting up	11
3.1	Establishing probe constant for length measurement with inversion of the probing direction	14
3.2	Programming retraction travel	19
3.3	Capturing a reference value	20
3.4	PRESET function	24
4	Display	25
4.1	Main display	26
4.2	Display format in mode measurement	27
5	Configuration menu	28
5.1	Unit system	28
5.2	Printing a language or header	29
5.3	Temperature stabilisation	29
5.4	Standard parameters	30
5.5	RS 232 input/output	31
5.6	Printer	31
5.7	Temperature compensation	32
5.8	Date and time	36
5.9	Header text	36
5.10	Default parameters	37
6	Features and functions	38
6.1	Measuring lengths using the function « Single probe contact »	38
6.2	Measuring lengths using the function « Dual probe contacts »	38
6.3	Measuring grooves	39
6.4	Measuring ribs	40
6.5	Measuring bores	42
6.6	Measuring shafts	45
6.7	Calculating a median	48
6.8	Calculating a distance	51
6.9	Measuring a diameter or a width	55



	F	Page
7	Entering the measuring instrument	56
8	Entering data through the keyboard	57
9	Capturing flatness and parallelism errors	58
10	Measuring angles	65
11	Measuring perpendicularity and straightness deviations	70
12	PAUSE	84
13	Characteristics of the measuring functions	87
14	2D measurement	90
14.1	Measuring in coordinate direction Y	92
14.2	Measuring in coordinate direction X	94
14.3	Checking 2D measurements	98
15	Performing 2D analyses	101
15.1	Translating the origin point of coordinates to the bore axis	101
15.2	Rotating the measured value through the main part	103
15.3	Aligning the coordinate system to the bore axis	104
15.4	Changing measured values into polar coordinates	106
15.5	Registering a measured dimension	107
15.6	Auxiliary geometric functions	108
15.6.1	Translating the coordinate system from the reference axis to new axis	110
15.6.2	Rotating the coordinate system through its origin point	111
15.6.3	Creating a fictitious origin point	113
15.6.4	Calculating the regression circle	115
15.6.5	Calculating the angle between 3 geometric elements	117
15.6.6	Calculating the distance between two points	118
16	Creating a part programme by learning	120
17	Managing files	123
17.1	Restoring a measurement programme	124
17.2	Editing a measurement programme	125
17.3	Cancelling a measurement programme	132
17.4	Managing measurement files	133



		Page
18	Executing a part programme	134
18.1	Simple 1D programme	135
18.2	Programme with angle, perpendicularity and 2D measurements	140
19	Statistics menu	150
20	Interfaces	156
20.1	RS 232 digital input	156
20.2	RS 232 digital output	157
20.3	CENTRONICS output and printer type (A4)	158
21	Printing formats	159
22	Exporting data files to PC	161
22.1	Data file format	162
23	Sales programme	162
24	Warranty	163
25	Declaration of conformity	164



1<u>) Main features</u>

In the tradition of the 1D control panel, your POWER PANEL plus M provides exceptional ease of use. Based on the concept *One Key* = *One Function*, it allows a direct and easy access to the variety of measuring and analytical functions available. The measured values are displayed along with a number of icons enabling a clear interpretation of the results.

Besides 1D measurement, your POWER PANEL plus M has the following additional features and functions:

- Possible use of two references A and B.
- Possible connection of an RS type instrument.
- Angle measurement.
- Perpendicularity measurement using either a measuring instrument equipped with an RS 232 output or a TESA IG-13 digital probe. Whenever two measuring instruments are connected simultaneously, the culmination point will be automatically detected with the digital probe coming first.
- 2D measurement with graphical representation of the coordinate axes available on display along with the measured part features.
- Creation of a part programme by learning.
- Automatic edition and generation of the measurement cycles. The memory can accept up to 9999 part features distributed in several part programmes, each including as much as 999 values.
- Memory capacity for 25.000 measured values.
- SPC capabilities with output of the average, range, standard deviation, histogram, actual/effective value comparison, number of out-of-tolerances values, control limits and control charts.
- Temperature compensation.
- Possible output of reports with all measurement and statistical data in A4 format.
- Two models available (with or without built-in printer).
- Connectors on the back panel:
 - Column: SUB-D connector, 15-pin female
 - RS output: SUB-D connector, 9-pin female
 - RS input: SUB-D connector, 9-pin male
 - TESA IG-13: MINI-DIN input
 - Printer: CENTRONICS output, 25-pin
 - Power input for the foot switch
 - Power input for the battery charger whenever the control-panel is used with TESA-µHite.



2) <u>Keyboard</u>

רסח 👰	
→ 123.5762… ©	
Ø 84.904 mm	
F1 F2 F3 F4 F5 F6	
🖂 🥌	
🖬 🏹 🏹 🖾 🔊 🛋 🚔	

F1 _à F6	Function keys
	Paper feed for built-in printer
ON OFF	Switching ON or OFF. Hold this key down (> 0,6 sec.) to validate your action.



	Transferring the value shown on the main display to a peripheral device. Press shortly to have this done (< 0,6 sec.) Transferring the whole contents of the table that includes the measured values to a peripheral device. Hold the key down (> 0,6 sec.) to have this done.
	Resetting the counter to zero. If the option « Header ON » has been selected, a new header can be entered each time this key is pressed. Also allows you to reinitialise the part programme created by learning.
	Cancelling the last function or the last probe contact.
	Measuring the centre and the width of a rib.
G ↓	Measuring parallelism and runout errors.
9	Calculating and further displaying the median obtained from the last two probe contacts or the last two numbered values you've selected earlier in the logbook.
	Cancelling both references A and B with return to menu St1/2 for taking a new reference A and/or B along with a new probe constant if you wish to. Also permits to reset the counter to zero and reinitialise the registration of the learn programme.
	Probing up once pressed shortly. Hold the key down to move the probe up quickly (desired speed is selected in the configuration menu). Probe will stop moving as soon as key is released.
	Probing up with detection of the highest culmination point.
	Probing up with detection of the lowest culmination point.



$\left[\stackrel{+}{\bigtriangleup} \right]$	Calculating and further displaying the difference value obtained from the last two probe contacts or the last two numbered values you've previously chosen in the logbook.
	Probing down once pressed shortly. Keep pressing this key to move the probe down quickly (for selecting the desired speed, use the configuration menu). Probe will stop moving as soon as key is released.
	Probing down with detection of the lowest culmination point.
V	Probing down with detection of the highest culmination point.
*	Displaying a bore or shaft diameter as well as the width of a groove or a rib whether temporarily or permanently (difference value obtained from two probe contacts).
SP	Measurement of the centre and the width of a groove.
	Measurement of both the centre and diameter of a bore.
	Measurement of both the centre and diameter of a shaft.
\Rightarrow	ENTER key to validate your action.



	Capturing the measured value from the tool connected to the RS 232 input.
	Entering data through the keyboard.
E	PAUSE key to stop the height gauge temporarily.
4	Measuring mode for angles.
Τ	Measuring mode for perpendicularity and straightness deviations. After exiting this menu, you'll either need to take the probe constant or have it captured again.
	2D measuring mode.
[∋°	Saving a part programme created by learning.
	Statistics menu.
S S S S S S S S S S S S S S S S S S S	Configuration menu.
X	Executing a part programme.



\square^{\vee}	Moving the cursor up by one single position or one field. In mode measurement, causes the programme to access the logbook and display the four measured values coming first. The remaining values will then appear in a subsequent order while moving forward in the logbook.
Z	Menu for managing files including part programmes and measurement results.
	Moving the cursor to the left by one single position or one field. In mode measurement, causes the programme to display the measured values at the rate of 4 while moving back in the logbook.
	Moving the cursor down by one single position or one field. In mode measurement, causes the programme to access the logbook and have the last four measured values displayed. The remaining values will then appear subsequently while moving back in the logbook.
	Moving the cursor to the right by one single position or one field. In mode measurement, causes the programme to display the measured values at the rate of 4 while moving forward in the logbook



3) Starting up





	Switching On	
ON	loo E	Press this key > 0,6 sec. to initialise your control panel and load correction values stored in the EEPROM of the
	POWER PANEL plus M Firmware V X.XX	standard column used. Firmware V X.XX shows the software version.
	Searching for the reference mark	
		Move up over a distance of approx. 100 mm, or down if you can't get any value. V-shaped sign indicates the direction to which carriage
	∧	moves.
	, s	
	Once you've travelled past the reference mark, probe insert will automatically position itself up to the centre of the master piece	
		Start probe constant acquisition using
		control by 1 click for probing internal part
		or pressing or for probing external part



	Accessing test menu	
2		
	: > Burn in, Moving up and down automatically :> Cancelling all data files :> Exiting test menu	
	Directoire programme: Delete all Files.	If you answer yes, all data files will be deleted along with the programme files
	Etes vous sur? NO YES	
	If no height gauge is connected when starting up: Display shows	
	EEProHD	Special cases 1) No communication with EEPROM
	: Access measurement mode without correction!	



3.1) <u>Establishing probe constant for length measurement with</u> <u>inversion of the probing direction</u>





Probe contact 3		
	+ C`	Probe contact 3 (up)
Displayed value after probe const	j	
	mm	Probe contact 4 (down)
±o≕ 4.9846 mm	Ta=22 4%C	Ready for capturing reference value
[♀ r=?		

- Displayed probe diameter is usually slightly smaller than the true diameter since the probe flexure is taken into account as the probe constant is being captured.
- Tc related temperature value only appears if you've selected Temperature Compensation.

	Capturing probe constant on the master piece (external part)	Position probe insert below the lower face of the master piece
	Probe contact 1	
0 SP		Probe contact 1 (up)
о С С С С С С С С С С С С С С С С С С С		Exit constant











Difference between the four measured values is too high	
Repeatability is checked again after probe contact 6 has been performed. If difference between the first and the third couple of measured values is too high, relevant value will be displayed.	Criteria : Resolution to 0,1 μm : <0.5 μm Resolution to 1 μm : <2 μm
	Resolution reduced to 1 µm Alternatives: Repeat value capture by pressing either key
	Validate captured value with delta to 1 µm by pressing key
Measuring in one coordinate direction	
Displayed data once you've pressed the function key	
	Ready for capturing reference value with a single probe contact
C ₽ T=22.4°C Γ ₽ Γ=? Γ	
Changing value of the master piece	
	Input new value
<u>⊠t</u> =? mm 	





3.2) Programming the retraction travel





	New value once entered (e.g. 10 mm)	
\Diamond	E E I mm	Ready for capturing reference value with a single probe contact
	r = 10.0000 mm $Tc=22.4^{\circ}C$ r=?	,

3.3) Capturing a reference value

Measuring without inversion of the probing direction: mode St-1

Capturii	ng refere	ence value	St-1 wit	h a single p	robe contact	
Ĵ@Ĵ	Ĺ		> ()	mm	,	Position probe insert close to the reference point to be probed, then start value capture by pressing the function
				Ŋ	P	probe contact or rotating the power control
) L	(r=?)		Ę	T=22.4°C	



rotate the power control by one click	 ∽ ∽	Mode St-1 Display shows one single probe V-shaped signs appear according to the direction to which the carriage moves. Number of signs at a speed of 7,5 mm/s = 1 or 15 mm/s = 2. At higher speed using the rotary power control = 3
		If value numbering isn't activated, display shows St-1 instead of M0

Measuring with inversion of the probing direction: mode St-2

Capturing reference value St-2 with two probe contac	ets
	Position probe insert close to the reference point to be probed, then start value capture by pressing the function key enabling one or two
፤ত− 4.9846 mm 🖯 📮	probe contacts or rotating the power control
Tc=22.4°€	s



	Approaching first probing point	
rotate the power control by one click		Mode St-2 Display shows two probes. V-shaped signs appear according to the direction to which the carriage moves. Number of signs at a speed of 7,5 mm/s = 1 or 15 mm/s = 2. At higher speed using the rotary power control = 3
	Approaching second probing point	
Once first probe contact has occurred, you may decide to activate St-2 or not		Mode St-2 Full contact V-shaped signs appear according to the direction to which the carriage moves. Number of signs at a speed of 7,5 mm/s = 1 or 15 mm/s = 2. At higher speed using the rotary power control = 3
		If numbering isn't enabled, display shows St-2 instead of M0
	LE ,	



Reference value will be equal to the mean value obtained from the two probe contacts.

Examples

1 By activating either of these function keys



either of the following actions will happen:

- If neither keys for *fast displacement* is pressed within less than 2 seconds, TESA Micro-Hite plus M will repeat the same function at the same location.
- If either of the keys for *fast displacement* is pressed within less than 3 seconds, you'll be able to select one of the 6 measuring functions available for probing another point.
- If the rotary power control is used to move the probe insert, TESA Micro-Hite plus M will repeat the same function at the new location.

In either case, the reference value will match the average of both probe contacts.

2 By activating either of these function keys



the reference value will be taken at the centre of the part feature to be measured.





3.4) PRESET function





4) <u>LC Display</u>

Consists of one main display (upper part) plus one auxiliary display (lower part). Display size: 128 x 63 mm.

Main display is split into segments (7-segment/sign), providing high visibility necessary to inspect parts most accurately.

Auxiliary display is a dot display, allowing a wide number of symbols to be created to make the height gauge easy to use and to learn.

Display mode for:

- Length measurement: measured values plus symbols for the functions.
- Perpendicularity and straightness measurement: measured values plus symbols.

Digit size:

- Main display: 12,7 x 6,4 mm (7-decade display plus minus sign)
- Auxiliary display: 6,3 x 4,2 or 3,8 x 2,9 mm (7-decade display plus minus sign)





4.1) <u>Main display</u>





4.2) Display format in mode measurement

	Large	
•		
	💋 24.9920 mm	
	Small	
		Display shows the last measured value in a large format plus the last four ones in a small format (main and auxiliary display).
	M 05 Reb int B 74.9963 M 04 Alésage 86.0510 24.9920 M 03 Pal Bas 160.0342 M 02 Pal Bas 115.0065 Tp=24.4°C Image: Comparison of the second secon	,



5) <u>Configuration menu</u>





To access submenus, press the key with the relevant letter or the arrow keys

to move the cursor. Next, confirm by pressing

To exit each submenu, press either of both following keys:

- Use this key if you want to validate all changes before exiting.
- Use this key if you want to delete all changes before exiting.

5.1) Unit format (A)

Allows you to choose the desired unit system for length and angle measurement as well as the resolution for the measurement results.

28

		Choose units and resolution with
to confirm your selection	Unit format Length: mm / inch Resolution: 0.0001 / 0.001 / 0.01 Angle: DMS / DEG / RAD	to confirm. To delete all changes and return to the configuration menu, press



5.2) Language / Header (B)

Allows you to choose your preferred language. If you've selected Header, you may set the relevant parameters as follows:

OFF Can only be activated in the configuration menu (submenu 1). **Loss** When starting up Execution of a part programme or pressing either l

When starting up Execution of a part programme or pressing either key

or Manual Section also prompts your control panel to reset the counter to zero.

Part When starting up Execution mode for measuring each single piece or

pressing either key or . This option also prompts your control panel to reset the counter to zero.

or the selection you've validated with	Lonfo B	Choose language and header with
	Language / Header Language: English Italiano / Espagna / Other Printer header : ON / OFF Introduction : OFF/ Loss / Part	then press to confirm To cancel all changes and return to the configuration menu, press

5.3) Speed / Stabilisation (C)

Allows you to set the desired probe speed for fast displacement or for approaching the measuring point. During the waiting time given for stabilisation, the measured value may only vary to the extent of the limit value, which depends on the selected resolution.

Criteria:

Resolution to 0,0001 mm Resolution to 0,001 mm Resolution to 0,01 mm Permissible variation $< 0.5 \ \mu m$ Permissible variation $< 1 \ \mu m$ Permissible variation $< 5 \ \mu m$

In most cases, we advise to activate the option AUTO for optimum waiting time and <u>best</u> results. The option % prompts you to validate your selection by pressing

key after each probe contact.

Your control panel will refer to the response times given for Displaying and Positioning when running a part programme. With respect to this, report to Executing a part programme (18) and Generating data files (17).





5.4) General parameter (D)

Automat. r	number When set to ON, the measured values are stored in the memory (switching the instrument off will stop registrat When set to OFF, only the last two measured values a available for calculating a median or a distance.	e ion). re
Display	When set to Large, display shows the last measured valu upper part whilst the second one, if any, appears in the lo part, both in large format. When set to Small, display shows the last measured valu large format in the upper part whilst the last four ones app in a small format in the lower part.	e in the wer e in pear
Print	With Manual, you won't be able to print until you press with Manual, you won't be able to print until you press with Auto, printing occurs after each value acquisition or comp operation.	uting
Beep : Auto OFF :	With ON, a loud beep sound warns you after each value acquis With the sign ½, a weak beep sound warns you after each value With OFF, beep sound is disabled. With ON, the instrument switches itself off as soon as preset tim With OFF, you won't be able to switch it off until you press	sition. le acquisition. ne is over.
or the	Lonf, B	Choose parameters with
validated with	General parameter Automat. Number: ON / OFF Display : Big size / Small size Print : Manuel / Auto Beep : ON / ½ / OFF Ext. P : Print / Measurement Auto OFF : ON / OFF Delay : 20 (min)	to confirm To cancel all changes and return to the configuration menu, press Time limit: 2 to 999 min.

N° ME07.99077

B. Vuille



5.5) <u>RS 232 input / output (E)</u>

Allows both to be activated as well as the desired format to be selected.

- Output With ON, output of the measured value only is prompted (Data output). With Printer SPC, data output includes the header (if any) along with the number and type of the measured dimension. With OFF, data output is disabled.
- Input With ON, data input is enabled. With OFF, data input is disabled.



5.6) <u>Printer (F)</u>

Allows you to activate the built-in printer (Model 00760220) along with the Centronics output of the A4 printer. The drivers you may choose are the following:

- A) Epson LX 80
- B) HP PCL (Ex:: HP Laser Jet 1200 series)

You're also allowed to select the desired paper length (9 to 13 inches). Standard length is 12 inches.

or the	Lonf, 9	Choose parameters with
validated with	PrinterInternal :ON / OFFIntensity :5A4 Printer :ON / OFFPrinter model :A / B / C / SPType:Epson LX 80Form length :9 / 10 / 11 / 12 / 13 ?	to confirm. To cancel all changes and return to the configuration menu, press



5.7) Temperature compensation (G)

If you're working in room that has no air-conditioning or if temperature of the workpiece is high, you may ask for a correction of the measured value while taking the variation in temperature of the workpiece into account along with its coefficient of linear expansion. To have this done, set Temperature Compensation to ON, then enter the temperature value of the workpiece with its related coefficient. The height gauge temperature will automatically be measured by the sensor at half height of the column.

You may input the workpiece temperature in either of the following ways:

- OFF: for use of the preset value from the configuration menu.
- Keyboard: for changing the value through the keyboard in measurement mode.
- RS : for capturing the value via the RS port in measurement mode.
- RS Auto : for automatic value capture via the RS port before each probe contact.

Switching the height gauge off causes your selection to be lost.



All values captured in this way will be corrected based on

the following information:

- T_R : Reference temperature (default value : 20°C)
- T_C : Height gauge temperature
- T_P: Workpiece temperature
- a_C : Coefficient of linear expansion of the height gauge
 - (fixed value available from the column)
- a_P: Coefficient of linear expansion of the workpiece
- H_{PM}: Workpiece height as measured

H_{PC}: Workpiece height once corrected

$H_{PC} = H_{PM} * (1 + a_C (T_C - T_R) - a_P (T_P - T_R))$

or the selection you've validated with	Lonfo 9	Choose parameters with
	Temperature compensation Compensation: ON / OFF Reference temp. : 20.0°C Part temp. : 25.9°C Part coef: 11.5 E-6 / K Temperature input : OFF / Keyboard / RS / RS Auto	to confirm. To cancel all changes and return to the configuration menu, press Temp + Coeff limit :



Height gauge temperature is displayed as the reference value is being captured. Workpiece temperature appears continuously after each probe contact.

Entering workpiece temperature

- In measurement mode with numbering excluded, you're always allowed to enter the workpiece temperature. Tough displayed value will not be assigned, the correction along with the new value for Tp will be effective with the next probe contact.
- In measurement mode with numbering included, you are not allowed to enter any value unless you've captured the first reference value or press the key
 - or to reach M0.
 - or to reach MU.
- In mode Executing a part programme, you may input the workpiece temperature as soon as the measurement process for a single workpiece or a part series is started.

Inputs (example)













5.8) Date and time (H)

Lets you enter the date and the time. Since your control panel includes a back-up type battery, these data remain stored in the memory even after the height gauge has been switched off.



5.9) Header text (I)

Predefined header provides 6 lines that can be complemented using the arrow plus alphanumeric keys. This 6-line header may also be entirely modified if necessary. The text you can edit using this option will include 31 characters per line. The header you've edited will remain stored even after the language has been changed or the height gauge switched off. To have the predefined lines appearing in the chosen language, the default header needs to be reinitialised (report to submenu J for more information).

or the selection you've validated with	Lonf, 9	Choose header location with
	Header text Part No:	text and press to confirm. To delete all characters, press
	Part name : Drawings No: Company: Operator:	


Ĩ		
O-9 Alpha/ numerical conversion	Lonf, 9	Choose header location with
	Header text Part No: Serial No: Part name : Drawings No: Company: Operator:	text and press to confirm. To delete all characters, press
Alpha/ numerical conversion	Header text	Choose header location with
	Serial No: Part name : Drawings No:	To delete all characters, press

5.10) Default parameters (J)

Use this option if you want to reset all configuring parameters to the default values.

If so, answer All to Parameters and Yes to Are you sure. Then Press 🖄 to confirm.

To reinitialise the header lines only, select Header and Yes, then press 🔊 to confirm.





6) Features and functions

6.1) Measuring lengths using the function « Single probe contact »



Without inversion of the probing direction:



With inversion of the probing direction:



6.2) Measuring lengths using the function « Dual probe contact »







Probing procedure	
A OT O D D D D D D D D D D D D D D D D D D D	Position probe insert in the groove by pressing both positioning keys or rotating the power control.
	Probe moves up automatically for first value capture.
\$ 	
	Single probe symbol appears as first value is being captured. Once retracted, probe insert comes to a standstill.























	Probe symbol appears as soon as probe insert has stabilised after contacting the workpiece feature.
^{//} ≪ ~ ∧	
, ,	
Moving the workpiece (or the vertical column) laterally allows automatic detect point with a BEEP sound and highlighted probe symbol to warn you. This point must be probed once (default setting). But, you may choose to trave pressing the ENTER key. If the value dispersion is exceeding 10 µm, an acoustic signal prompts you to procedure. The option you've selected remains stored for each probe contact with detecti point. To return to the single probe contact option, press the Enter key again gauge off.	tion of the culmination el past this point twice by repeat the probing on of the culmination or switch the height
	Highlighted symbol for detection of the culmination point.
	Probe moves down. For faster displacement, use the rotary power control.



		Probe symbol appears as soon as probe insert has stabilised after contacting the workpiece feature.
R	Moving the workpiece (or the vertical column) laterally allows automatic detect point with a BEEP sound and highlighted probe symbol to warn you. This point must be probed once (default setting). But, you may choose to trave pressing the ENTER key. If the value dispersion is exceeding 10 μ m, an acoustic signal prompts you to procedure.	tion of the culmination el past this point twice by repeat the probing
		Once culmination point is detected, probing procedure is ended. Probe retraction occurs automatically. Display switches over to normal display.
	Ø 24.9920 mm □ ↓ △ Ø ₽	





Probing procedure	
	Position probe insert below the diameter to be measured by pressing both positioning keys or rotating the power control.
Ø 24.9920 mm □ ↓ Ø 및 ,	Release the measurement cycle by pressing the relevant function key.
	Probe moves up.
	Probe symbol appears as soon as probe insert has stabilised after contacting the workpiece feature.



	Moving the workpiece (or the vertical column) laterally allows automatic detection of the culmination point with a BEEP sound and highlighted probe symbol to warn you. This point must be probed once (default setting). But, you may choose to travel past this point twice by pressing the ENTER key. If the value dispersion is exceeding 10 μ m, an acoustic signal prompts you to repeat the probing procedure. The option you've selected remains stored for each probe contact with detection of the culmination point. To return to the single probe contact option, press the Enter key again or switch the height gauge off.	
		Highlited symbol for detection of the culmination point. Once retracted, probe insert comes to a standstill.
or use the rotary power control		Position probe insert above diameter to be measured by pressing both positioning keys or rotating the power control.
or rotate power control by one click		End measurement cycle by pressing ENTER or rotating the power control. Probe moves down.







6.7) <u>Calculating a median</u>

Provided the value numbering option is not selected, you can access this function any time

by pressing . The median is usually calculated from the measured values obtained for both part features that were last displayed.



At this point, your Power Panel *plus* M gives you the choice between three possibilities :

- Store median value as a M06 dimension with the aid of the function key F6 \square

N° ME07.99077

B. Vuille



Skip value storage and access directly the function by pressing for calculating a new median (M?? M?)

- Skip value storage when carrying out the measurement directly











6.8) <u>Calculating distances</u>

Providing the option Value Numbering was not selected earlier, you can access this function any time by pressing . A distance value is usually calculated from the measured values obtained for both part features that were last displayed.







At this point, your Power Panel *plus* M gives you the choice between the following possibilities:

- Store distance value as M06 dimension by pressing function key F6 $M^{=?}$
- Skip value storage and access directly the function by pressing for calculating a new distance (M ? M ?)
- Skip value storage and take the measurement directly.





	Calculating distance value based on chosen or keyed in va	alues
$\left[\begin{array}{c} {}^{\!$	M 5 Reb. int B 74.9963 M 4 Palp Bas 205.0232	Auxiliary display shows the last four values from the table. Higher value is highlighted.
	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	
	Skip one measured value upwards. Skip one measured value downwards. Skip one page (4 values) upwards. Skip one page (4 values) downwards.	Choose desired values using the arrow keys or enter value number through the keyboard
\Rightarrow		Display shows desired value (M5) along with the last four ones from the table. Higher value is
	M 4 Palp. Bas 205.0232 M 3 Palp. Bas 160.0342 M 2 Palp. Bas 115.0065 M 1 Palp. Bas 55.0225 mm	highlighted,
3 times		Choose displayed value M1 as first parameter for calculating
ΔΥ	M 4 Palp. Bas 205.0232 M 3 Palp. Bas 160.0342 M 2 Palp. Bas 115.0065 M 1 Palp. Bas 55.0225 △ M 5-M ④	distance value.







6.9) Measuring a diameter or a width





7) Entering the measuring instrument

This input allows the connection of an opto-electronic measuring instrument, RS type, which can be purchased from TESA or any other manufacturer. The following parameters can be altered as desired in the configuration menu:

Data rate: Character length: Start : Stop : Parity : 4800 bauds 7 bits 1 bit 2 bits even

Transmission format :

With use of the cable No. 04761049, bidirectional : as above or opto-RS With use of the cable No. 04761046, monodirectional : 4800 bauds (or 1200 bauds for a measuring instrument from an earlier generation), 7b, 2P, 2S, oh.





8) Entering data through the keyboard





9) Measuring flatness and parallelism errors

You may access the menu MAX/MIN from any position within part programs by simply activating the function key 🖾.

To exit this menu and return to the reference mode you've previously quitted, press F6 🔜



















	Exiting menu	
		Return to main display All subsequent measurements will be taken based on the reference value you've activated before accessing menu <i>Measuring</i> <i>parallelism</i> <i>errors.</i>
	Prompting for parallelism measurement in ABS mode	
Г <mark>а</mark> ьс		Display shows value measured against active reference value. If St-1 is enabled, you may only press F1 or F2 according to the probing direction.
or rotating the power control		Display shows value measured as probe is being displaced. V-sign indicates probe moving direction. Rotary power control may be used for approaching the relevant point.











10) <u>Measuring angles</u>

To access this menu, press

Next, the following submenus is available:

Angle of any inclined surface to the reference surface









	Probing gauge block	
Е		Probe first point on the gauge block.
	x1= 0.0000mm	
		Probe second point on the gauge block. Relevant angle = arc tg (P2-P1)/X
XZ	P1 52.8762 F Deg RAD () () () () () () () () () ()	calculated. Display shows calculated value in selected unit.
	DMS Conversion into degree, minute and second Deg Conversion into decimal degree RFD Conversion into radian X+ Conversion into radian	Perform new probe contact or exit Mode 1
	Storage of X value for all subsequent angle measurements. If a part programme is created by learning, this value remains constantly available in the memory and it will not be necessary to enter it again bye executing the programme.	



	Changing units of measurement	
Deg	$ \begin{array}{c c} M & A \\ \hline \hline$	Temporary conversion into degrees.
RAD		Temporary conversion into radian. Press F4 to replace radian by the unit you've previously selected by pressing F3.
	Entering gauge block dimension	
	$ \begin{array}{c} \mathbb{P} & \mathbb$	Prompt for value input once you've probed point P2.
()	$\begin{bmatrix} \psi & \psi & \psi \\ \psi & \psi & \psi \\ \psi & \psi & \psi \\ \psi & \psi &$	Activate value input.





11) Measuring perpendicularity and straightness deviations

Your POWER PANEL *plus* M allows you to establish perpendicularity and straightness deviations using the TESA IG-13 digital probe or an RS type measuring instrument. Form and position errors are captured according to ISO 1101. For more information on the way to proceed when measuring, read chapter 4.17 in the instruction manual that came with your TESA Micro-Hite plus M height gauge.



Fig. 2 Trois positions de crantage pour le placement correct du palpeur TESA IG-13



You may access the mode that allows you to measure perpendicularity and straightness deviations in either of the following ways :

- Automatically by switching on your height gauge providing TESA IG-13 is connected to the control panel.
- By using the function key \blacksquare from the main menu.

	Accessing mode by switching on	
ON OFF		Search for the reference value. Detect whether TESA IG-13 is connected. Test whether an RS tool is used. Ignore all other keys
	<u>First option</u> : TESA IG-13 could be recognised by switching the heir <u>Second option</u> : Function key C could be prompted. Whenever th with TESA IG-13 are simultaneously connected, priority is given to	ght gauge on. le RS tool along the IG-13.
 Travelling past reference mark with automatic recognition of TESA IG-13. Prompting for function key 		Display shows computed value in Z axis along with probe direction. Wait for reference mark to be passed over by moving probe insert manually.
	<u>First option</u> : Reference mark could be passed over by moving the the probe manually. <u>Second option</u> : RS tool could be recognised whilst no probe was c	measuring bolt of connected.



 Travelling past the reference mark Using connected RS tool 		Main display shows computed value in the Z axis Auxiliary display shows computed value that refers to IG-13 (or RS tool) along with probe direction in either of both X or ±Y axis. With use of an RS tool, you're allowed to measure in the X axis only
	Entering a PRESET value in the Z axis Setting the counter to zero in both X and Z axes. Entering the measuring range in the Z axis. Entering the measuring range in the X axis (based on the gr	aph scale)
	No probe or dial gauge could be recognised when accessing	measuring mode
Ľ		Prompt for rejected measured value - No IG-13 probe or dial gauge is connected. Press the key to
		return to standard mode or to access Z mode with disconnected probe.
or		Access to Z mode with disconnected probe. Press I to quit this mode and return to standard mode.
	[<u></u> 0.0 _	


	Measuring perpendicularity and straightness deviations	
	IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	Displayed data before starting up the measurements
	 There are several ways to start up your probing operations. Activating this key or rotating the power control clockwise by you to start probing up. Activating this key or rotating the power control counter clocklets you start probing down (the speed (v) at which probe will movinitially set to ON in the configuration menu). Image: Activating this key lets you start probing while keeping probe under control using the rotary power control. 	one click allows kwise by one click e should have been displacement (v)
		Start measurement Display shows single Z axis.
or rotating the power control	×	



	As you're measuring you may also activate the following keys:									
	To stop value capture and probe displacement.									
	To end value capture. You may also use the rotary power control.									
	To aboard the value capture.									
	Prompting for PAUSE mode									
E	PRUSE ★ 115.0065mm Z= 115.5345 mm	Stop data acquisition. Display shows current value along with the value captured in Z axis as this mode was accessed								
	Exiting PAUSE mode									
		Start data acquisition back again								



	Fin de la prise de la mesure. Affichage général	
or rotating the power control	$ \begin{array}{c} $	Full display shows measurement results Measuring perpendicularity error appears on main display. Measured straight- ness deviations, angle and range in Z axis appear on auxiliary display.
	At this point, you may decide to prompt for either of the following c	options:
	Perpendicularity error	
	Highest measured value with its position	
	Lowest measured value with its position	
	Straightness angle	
	Straightness error	
	Curve diagram of measured values	
	Printing measured values	
	Use these keys or the rotary power control to start measurement.	a new
	Use this key to get data displayed when starting up back aga values and logbook will not be initialised.	in. The reference
	Use this key to exit the perpendicularity measuring mode.	







	Prompting for perpendicularity error							
<u></u>	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	Main display shows perpendicularity error (Max-Min). Auxiliary display shows measuring range in Z axis.						
	At this point, you may decide to press either of the following keys	:						
	M=? to save measured value in the logbook (provided value nun enabled in the configuration menu).	nbering was initially						
	to print measured values related to both perpendicularity error	or and Z range.						
	or Use either of both keys to return to measurement re displayed.	sults - previously						
	Use these keys to access other measured values.							
	Use these keys or the rotary power control to start measurement.	a new						
	Use this key to get data displayed when starting up back aga values and logbook will not be initialised.	in. The reference						
	: Use this key to exit the perpendicularity measuring mode.							
M=?)	n 1 © 1,1560m	Save measured value in the logbook.						
	$\underline{h} = 0.1560$ Z = 115.0065							



	Prompting for highest value		
¢ ∔	De D		Main display shows highest value (Max) while its position in Z axis appears on the auxiliary display
	∲→ = 0.0715 mm Z= 74.9963		
	From this stage, you may ask for all operations described unde perpendicularity error » to be executed accordingly.	r «	Prompting for
M=?			Save highest value in the logbook.
	<pre></pre>		
	Prompting for lowest value		
⊫⊸			Main display shows lowest value (Min) while its position in Z axis appears on the auxiliary display.
	⊷ = 0.0000mm Z = 0.0000 mm		



	From this stage, you may ask for all operations described under « perpendicularity error » to be executed accordingly.	Prompting for
M=?	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	Save lowest value in the logbook.
	Prompting for straightness angle	
¥		Main display shows straightness angle.
	\checkmark	
	At this point, you may press either of the following keys : and RD to change temporarily angle unit into decimal degree or to return to displayed measurement results of Use these keys or the rotary power control to start measurement. M=?, M, M, L : to activate the same functions as describe chapter.	e or radian. a new ed earlier in this
M=?		Save straightness angle in the logbook.
	Deg RAD	



		Return to measurement results of - previously displayed.
	$h = 0.1560 \ll = 0^{\circ} 04'41''$	
	Prompting for straightness error	
		Main display shows measured straightness error.
	From this stage, you may ask for all operations described under	« Prompting for
(Georgean)		Save straightness
M=?]		angle in the logbook.
		Return to measurement results of - previously displayed.



	Prompting for graph curve of measured values	
ÎZ,	x c.164	Auxiliary display shows graph curve along with Z range. The main display shows the measuring Z range.
	From this point, you may press either of the following keys : or C: to return to measurement results of - previously dis C: to return to measurement results of - p	splayed. a new ed earlier in this
	Entering PRESET value in Z axis	
Ŷ	mm	Input PRESET value.
Entering 100,0 through the keyboard		Displayed value once entered. Confirm by pressing Solution and press F2













Use this function key to activate the still mode. Once this is done, you may continue measuring based on a new reference C. The measured values will not be kept in the memory and the measurement cycle will not be interrupted. When capturing deviations in parallelism and perpendicularity, this function also serves to temporarily stop value capture, e.g. when getting over a groove (see chapter 9 and 11 for more information).

		PAUSE can be prompted from the measuring mode.
	💋 24.9920 mm	
E	PAUSE	System has switched over to the standby condition.
	To access reference C temporarily	e.
	In the PAUSE mode, you're not allowed to capture a new pr as this operation could affect the measurement cycle being the time this mode was enabled. You may, however, use th enabling you to perform all needed probe contacts or meas or medians.	robe constant g carried out at e functions sure distances











13) Characteristics of the measuring functions

Each measuring function is given a name along with a single or several measured values.

Fonction	N°	Туре	Ref	Axe	Val 1	Val 2	Val 3	Unité Cote	Texte Nom
	M01	Pal H	A	Z	xxxx.xxxx	-	-	mm	
5 N	M02	Reb int H	A	Z	xxxx.xxxx	-	-	mm	
	M03	Reb Ext H	A	z	xxxx.xxxx	-	-	mm	
	M04	Pal B	A	Z	xxxx.xxxx	-	-	mm	
	M05	Reb int B	A	Z	xxxx.xxxx	-	-	mm	
₹ ▼	M06	Reb Ext B	A	Z	xxxx.xxxx	-	-	mm	



Fonction	N°	Туре	Ref	Axe	Val 1	Val 2	Val 3	Unité Cote	Texte Nom
0 SP ▼▲	M07	Rainure	A	Z	xxxx.xxxx	xxxx.xxxx	-	mm	
	M08	Tenon	A	Z	xxxx.xxxx	xxxx.xxxx	-	mm	
•	M09	Diam Int	A	Z	xxxx.xxxx	xxxx.xxxx	-	mm	
	M10	Diam Ext	А	Z	xxxx.xxxx	xxxx.xxxx	-	mm	
8 ∕_∳	M11	Batt	- Si Abs A	Z	Max xxxx.xxxx	Min xxxx.xxxx	-	mm	
9 <u></u>	M12	Моу	A	Z	xxxx.xxxx	-	-	mm	
$\left[\begin{array}{c} + & \\ - & \\ \end{array} \right]$	M13	Delta	A	Z	xxxx.xxxx	-	-	mm	
	M14	RS	-	-	xxxx.xxxx	-	-	mm	
	M14	Clav	-	-	xxxx.xxxx	-	-	mm	

POWER PANEL plus M

Fonction	N°	Туре	Ref	Axe	Val 1	Val 2	Val 3	Unité Cote	Texte Nom
	M15	Ang. 2Pal	A	-	Palp 1 xxxx.xxxx	Palp 2 xxxx.xxxx	X xxxx.xxxx	Rad	
μ									
-9	M18	Perp	-	Perp	?X xxx.xxxx	?Z xxxx.xxxx	-	mm	
¢ -	M19	Perp max	-	Perp	Xmax xxx.xxxx	Z xxxx.xxxx	-	mm	
₽	M20	Perp min	-	Perp	Xmin xxx.xxxx	Z xxxx.xxxx	-	mm	
A	M21	Ang. Perp	-	Angle	x.xxxxx	-	-	Rad	
	M22	Rect	-	Rect	xxx.xxxx	-	-	mm	





To access this mode from the standard mode, the following conditions must first be met:

- Probe constant has been established prior to access mode.
- Reference value has been captured at least at the time you were accessing this mode.
- Numbered values possibly saved in the logbook have been retained or erased by answering displayed warning message appropriately.

To measure the centre heights, you may proceed in either of the following ways :

- With detection of the culmination point by pressing sing or
- Without detection of the culmination point by pressing a or a logical or a logical or logical or

Fonction	N°	Туре	Ref	Axe	Val 1	Val 2	Texte Nom
Ø SP ▼▲	H1	Centre mm	A	Y X	xxxx.xxxx xxxx.xxxx	xxxx.xxxx xxxx.xxxx	
▼ F ▲	H2	Centre mm	A	Y X	xxxx.xxxx xxxx.xxxx	xxxx.xxxx xxxx.xxxx	
(•)	H3	Centre + Diam Int mm	A	Y X	xxxx.xxxx xxxx.xxxx	xxxx.xxxx xxxx.xxxx	
	H4	Centre + Diam Ext mm	A	Y X	xxxx.xxxx xxxx.xxxx	xxxx.xxxx xxxx.xxxx	



	Common measurement in mode St-2	
2 V		Activate St-2
	Entering in measuring mode 2D	
		M values saved in the logbook may either be retained or erased if automatic numbering bas
	Effacer les valeurs: ?	been selected. In this example, Yes prompts for next value M1. No prompts for next value M6
	Starting up 2D measurement in Y axis	
ND or		
YES]	Image: wide wide wide wide wide wide wide wide	
	Exit 2D measuring mode Prompt for manual input of relevant number Rotation through X axis	



14.1) Measuring in coordinate direction Y









End Measuring in coordinate direction Y.



14.2) Measuring in coordinate direction X



	Prompting for workpiece rotation	
۲.		Confirm default value (angle to 90°) or displayed value if you've previously pressed F5 .
		You may also change angle unit or input a new angle value.
	RAD Deg	Rotation angle is limited to \pm (45° to 135°).
$(\mathbf{\hat{F}})$	X=	Validate workpiece rotation.
	mm	
	×1	



	Measuring in X axis	
		Probe bore 1 with detection of the culmination point.
	×₁ Ø 45.0120 Hx 3 ↓ Tp= 23.02° c ↓ ↓	next in the table is proposed in the order of the probe contacts made in X axis.
		Display shows measured value H 1 (X).
		Probe bore 3 with detection of the culmination point.
	×↑ Ø 25.0260 → Hx 6 ↓ Tp= 23.02° c	Bore that comes next in the table is proposed in the order of the probe contacts made in X axis.
•		Probe bore 6 with detection of the culmination point. Bore that comes next in the table is proposed in the
	׆ ∅ 15.0080 🚍 ^H x 7	order of the probe contacts made in X axis.
	Tp= 23.02° c	Data can either be analysed or checked at the end of the couples of probe contacts.

End Measuring in coordinate direction X.

The measurement results can be checked before 2D analysis is started up. You may also decide to measure the part features that were skipped earlier. To do so, proceed as described on the following pages.









End Measuring in both coordinate directions X and Y.

At this point, you may activate either of the following keys :



To define the origin point of the coordinate system



To calculate the regression circle based on measured part features



To check the measurement results



: Initialise the register of measurement, quit the 2D mode and return to the reference M0.



Initialise all 2D measurements (H et M) and return to the beginning of the 2D mode.



14.3) Checking 2D measurements :







WW Keep pressing this key, to print all values of the H elements.







At this point, you may either return to the probing mode by pressing conduction or access the 2D analysis mode by activating the function key to have the origin point of the coordinate system be first determined.





15) <u>Performing 2D analysis</u>

A 2D analysis allows you to execute various operations such as levelling and selecting the coordinate system or the numbered values M you want to print out. First, you need to determine the origin of the coordinate system.

15.1) Translation of the origin of coordinates to the bore axis









From then on, you may decide

to view the other part features using the arrow keys

- to ask for next feature to be displayed
- Let to aks for previous feature to be displayed
 - to jump forwards by 4 features
- I to jump backwards by 4 features

or to access desired part feature directly using the keyboard. In this case, confirm by pressing

Available functions :

- Conversion into polar coordinate system
- . 🖶

New point of origin



Alignment of the coordinate system

_ [t_{ø+}

Rotation of measured value through the main system

- _ [M=?
- Registration of the measured value shown on the main display as Mn+1 providing automatic value numbering is set to On. When saving a part programme, this value alone will be saved as measured dimension.



Auxiliary geometric functions

Press shortly: Print the value appearing on the main display Keep pressing this key to print all M and d elements values.



15.2) <u>Rotation of displayed value through the main system</u> t_{\varnothing}





15.3) <u>Aligning the coordinate system to the bore axis</u>











15.4) Changing measured values into polar coordinates



Changing into cartesian coordinates



15.5) <u>Registering a measured dimension [1=?]</u>

Use the arrow keys together with $\underbrace{t}_{\text{subset}}$ to choose the value you want to save in the constant table M – i.e. the distance between both part features 1 and 3 in the example shown below.



Important : When executing a part programme by learning, you won't be able to view any numbered value, except for those saved in the constant table M.





15.6) <u>Auxiliary geometric functions</u> 器

Have part feature 6 being displayed in polar coordinates before going on.






Available functions

- Translation of coordinate system to another part feature
 - Rotation of coordinate axes through a given angle
 - ____ Definition of of the coordinates of a fictitious origin point
 - Calculation of the regression circle
 - Storage of the measured value shown on the main display as Mn+1 providing automatic value numbering is set to On. When saving a part feature, this value alone will be saved as measured dimension.



M=?

Return to main geometric functions

The following functions may either be accessed from the main or auxiliary geometric functions.



Calculation of angle value between 3 part features

- Calculation of the distance between 2 points, i.e.:
 - distance, ΔX plus ΔY in both X and Y coordinate axes
 - distance, ΔR plus ΔA ngle in polar coordinate system



15.6.1) <u>Translating the coordinate system from the reference axis</u> to new axis







15.6.2) Rotating the coordinate system through its origin point









15.6.3) <u>Creating a fictitious origin point</u>























15.6.5) Calculating the angle between 3 geometric elements





15.6.6) <u>Calculating the distance between 2 points</u>









16) Creating a part programme by learning

To create a part programme by learning, you need just measure as usual, then press the key as detailed in the example that follows.







All measured values captured since you've switched your height gauge on will be registered together with those related to the probe constant <u>or the references</u>. If you

don't want to include constant or reference values, activate is to instruct the programme to only store those values measured since that time you've pressed this key.



To create a 2D part programme, proceed in the same way. You may also access this mode after you've carry out a number of 1D measurements.

Procedure:

- Capture constant value prior to reference value <u>« St2</u> » by pressing
- Set counter to zero, if necessary, by pressing
- Perform 1D measurements, if required (optional)
- Access 2D mode by pressing
- Perform 2D measurements (Hy....Hx)
- Establish the origin of the coordinate system with alignment (levelling, d01...dn)
- Execute needed calculation, then assign desired numbered values (M01......Mn)
- Create a learn programme file where this procedure will be saved by pressing This file will contain the values captured in either of both 1D and 2D modes as well as those obtained when measuring angles or parallelism errors.

<u>Note</u>: You won't be able to create a part programme by learning unless you've enable automatic value numbering.







To load numbered values from the programme into the memory back again. At this point, you're also allowed to add any value, especially in 2D mode.

EDIT

To edit a desired part programme where you may add tolerance values or enter or erase numbered values.



To delete selected part programme in the memory.

To access data files with the measurement results.

To exit from relevant menu.



17.1) <u>Restoring a measurement programme</u>

Z	Directoire programme: Free Size: 654KB DEMO01 DEMO04 DEMO02 DEMO05 DEMO03 DEMO06 DEMO06	Prompt for managing files Make your selection using the arrow keys. The ON/OFF key cannot be activated when managing or editing files. Cursor shows programme file you've last
		created.
Ð	FILES	Confirm both displayed file and data.
	Directoire programme: Load File DEMO01 Load Data DEMO01.00	
		Provided constant and reference values have not been changed in the meanwhile.
	△ M5-M4	display shows data as they were as you've saved the part programme.

<u>Note</u>: This option lets you get back the measured values you've stored before switching your height gauge off, for instance. You may also add two-dimensional dimensions, what is not allowed from the edition menu.



17.2) Editing a measurement programme

Ľ	FILES	Prompt for managing files Make your selection using the arrow keys.
	Directoire programme: Free Size: 654KB DEMO01 DEMO04 DEMO02 DEMO05 DEMO03 DEMO06 Image: Difference of the second secon	cannot be activated when managing or editing files. Cursor shows programme file you've last created.
EDIT	Edoboan	Edit chosen tolerance and printing options. The programme based
	DEMO01 T±OFF /ON n = 0 Echantillons Imprimante Int. : Cotes hors tol. Sortie RS : Toutes les cotes	configuration can only be changed from this menu.
	NEXT ELIT	

T±OFF/ON: To work with or without tolerances (arrows ? and ?).N = 0: To define the sample size if you want to use control limits.A4 printer:Built-in printer:RS outputs:

So as to have the desired values printed on your reports, you may choose between the options available from each of the three outputs, namely:

- All dimensions
- Out-of-tolerance dimensions
- Classification

To move from a field to another, use the arrow keys ? and ? .

To select the print command, use the arrow keys? and?



To move to the next programme sequence.

To print the selected part programme if you hold this key down (only on A4 printer).

NEXT		Displayed constant value which may needs to be captured as the programme is started up.
		If not, jump to the next step.
NEXT	mm	Capture reference value. You may also input a preset value or enter desired retraction travel.
		Capture constant value as the programme is
	r=? Insert Delete Next EDIT	required. If not, jump to the next step (M1).
NEXT		Display shows probing direction to capture the reference value.
	Pal. Bas	
	H-2 0-9 INSERT DELETE NEXT COUT	
NEXT		Common case: Display shows entered tolerances with both control limits UCL and LCL.
	Pal. Bas Nominale: \pm 55.0000 T± ON UCL X 0.0000 LCL X 0.0000 T+ 0.6500 UCL S 0.0000 LCL S 0.0000 T0.1000 UCL R 0.0000 LCL R 0.0000 Auto Pos INSERT DELETE NEXT EUT	If displayed sample size is 0, this means that no control limits will be displayed and entered.





To move from a field to another, use the arrow keys ? , ?

T± ON Probing down	Use the arrow key? to set this option to OFF. Default name corresponds to the definition of the probe contact to be made. Once you've accessed this field using the arrow keys, you may
	enter a specific name for each numbered d value (max. 16 characters).
	If so, confirm each entry by pressing 🔛
Nominal	Default value is displayed when creating the part programme. Once
	you've accessed this field using the arrow keys, you may ask for the
	relevant nominal value to be edited. If so, confirm by pressing

Proceed in the same way to edit desired tolerances.

- T+ Upper tolerance limit
- T- Lower tolerance limit
- UCL X Upper control limit for X (mean of sample)
- LCL X Lower control lmit for X
- UCL S Upper control limit for S (standard deviation of sample), non-active
- LCL S Lower control limit for S, non-active
- UCL R Upper control limit for R (range of sample), non-active
- LCL R Lower control limit for R, non-active



	Direct access to a dimension	
[] ← B 2: n		Prompt for listed dimensions Select desired dimension using
	M 4 Paip. Bas 205.0232 M 3 Paip. Bas 160.0342 M 2 Paip. Bas 115.0065 M 1 Paip. Bas 55.0225 M 1 Paip. Bas 55.0225 M =? \bigotimes	the arrow keys or enter relevant number through the keyboard. Confirm by pressing
	Inserting a dimension	<u>.</u>
INSERT	mm	First choose the programme step you want to be inserted before the one shown on display : - Capturing
		constant value (F1) - Capturing reference value (F2) - Capturing a measured value by pressing the relevant key.
(•)		Entering a bore centre instead of numbered value M1
	= ? ∅ = ? № NEXT	Input bore centre and diameter through the keyboard.













17.3) <u>Cancelling a measurement programme [DELETE]</u>

Z	Directoire programme: Free Size: 654KB DEMO01 DEMO04 DEMO02 DEMO05 DEMO03 DEMO06 DELETE DATA	Prompt for managing files Select desired programme file using the arrow keys. Do not use the ON/OFF key while both managing and edition modes are activated. Programme file which was last saved is pointed.
DELETE	FILES	Confirm your selection by answering prompt accordingly. All related data
	Delete File DEMO01 Delete Data Files DEMO01.0105	files are automatically cancelled as selected file is
	Es-te vous sur?	from the programme.
YES	FILES	
	Directoire programme: Free Size: 654KB DEMO04	
	DEMO02 DEMO05 DEMO03 DEMO06	



17.4) Managing measurement files

Z	Directoire programme: Free Size: 654KB DEMO01 DEMO04 DEMO02 DEMO05 DEMO03 DEMO06 DET DELETE DATA	Prompt for managing measurement files Select desired data file using the arrow keys. Do not use the ON/OFF key while both Generation and Edition modes are activated. Programme file which was last saved is highlighted.
DATA	FILES	Prompt for result files Select desired file using the arrow keys.
	Directoire résultats:Free Size: 654KBDEMO01.01DEMO04.01DEMO01.02DEMO04.02DEMO01.03DEMO04.03DELETEPROG	To erase files one after the other, use the function key
	To exit this mode and return to the measuring mode, press the function key	



18) Executing a part programme

The configuration menu provides a number of parameters which may need to be specifically set for each part programme. The settings that need be made for running this part programme are described as follows:

- Probing speed: 7,5 / 15 mm/s
- Fast displacement: 20 / 30 / 40 mm/s. Probe will automatically be positioned at the selected speed when starting probing.
- Response time of display: given value indicates in seconds how long display remains blocked before next numbered value appears. This options is enabled when AUTO is set to ON.
- Waiting time for stabilisation: given value indicates in seconds how long you've to wait before starting probing after the probe has reached its correct position. This option is enabled when POS is set to ON.

		Prompt	Positioning	Response	Waiting	Displayed
AUTO	POS	for next		time of	time for	value
		unnension		uispiay	StabiliSation	
OFF	OFF	Enter	Manual + Enter to start probing	Infinite	Infinite	Last measured value. Next value is prompted once Enter is pressed.
OFF	ON	Enter	Auto	Infinite	As set	Last measured value. Probe is positioned once Enter is pressed. Next value is prompted once given waiting time is over.
ON	OFF	Auto	Manual + Enter to start probing	As set	Infinite	Last measured value. Next value is prompted once given response time is over. Subsequent value is prompted once Enter is pressed.
ON	On	Auto	Auto	As set	As set	Last measured value. Probe is positioned once response time is over. Nex value is prompted once waiting time is over.

<u>Note</u> : The function key F6 may be activated instead of Enter or the power control may be rotated by one click.



18.1) <u>Simple 1D programme :</u>

Follow this procedure to execute a part programme:

	Accessing the Execution mode	
X	Directoire programmes: DEMO01 DEMO02 DEMO02 DEMO03 DEMO06 DEMO07 START	Choose desired measurement programme Select desired file using the arrow keys Press F1 to return to St-1/2.
	Special case as this mode was first prompted	
START	Fichiers data: DEMO01 Copie DEMO01.00 > DEMO01.01 Nouveau fichier	Use Start if you want the values measured in the Learn mode to be loaded in data file 01. Relevant workpiece will be given the number 1. If not, move the cursor to new file.
	Procedure if numbered value M1 must be captured as the part programme is started up AUTO ON/OFF and POS ON/OFF as described hereafter	
$\left {\Rightarrow} \right $		Example with creation of a new data file. If, the copy of the 1 st part is choosen, the unit
	Tp = 22.5°C END Pièces 1	will display the end of the cycle and indicate the classification.



START		Display shows next part feature to be probed
e I		Condition : M0 : Auto/OFF,
depending on previous	87.0000	M1 : Pos/OFF Position probe
setting or using the rotary power control	M 1 Alésage 🕢 🔊 🗩	manually.
Ð		Probe relevant bore
or		
⊲≫		
or using the rotary power control		
Numbered value M1 has been		Display shows numbered value M1
captured	ตั้ ั _่ ผ้ วิ	Proposal for M2: calculating bore
	💋 24.9920 mm	diameter M1 Condition :
	M 2 Alésage Diamètre 🛛 🔊 🗩	M1: Auto/OFF M2: Pos/ON
		Display shows bore diameter
or		M2 along with next measurement to be taken
\Rightarrow		Conditions : M2 : Auto/ON M3 : Pos/ON
or using the rotary power control	M 3 Palpage Bas	



Automatic positioning	M A 249920mm 55.0020	Probe is automatically positioned to the part feature M3. Positioning options: - at the centre of a bore or a groove -3 mm away from the surface to be probed once for
	M 3 Palpage Bas	a shaft or a rib
Automatic positioning is ended		Activate double beep sound once probing point has been approached
	55.0020	function M3 as soon as the required waiting time for
	M 3 Palpage Bas	over.
Automatic capture of numbered value M3		Probe part feature M3
	~~	
Numbered value M3 has been captured		Display shows numbered value M3 along with next measurement to be taken
		Condition: M3 : Auto/ON, M4 : Pos/ON
	M4 palpage Bas	



Automatic positioning as set	M I Image: Second state Image: Second state Image: Second state Image: Second state Image: Image: Image: Second state Image: Second state Image: Ima	Probe is automatically positioned to the next part feature (M4).
	M4 palpage Bas	
Numbered value M4 has been captured		Display shows numbered value M4 Response and
		waiting times are those previously entered in the configuration mode.
	M 5 Distance M4-M2 🔊 🗊	
Depending on your settings in the edition mode (e.g. AUTO/OFF for M4)		Display shows numbered value M 5 Last measured value usually includes :
or	Pièces 1: 🖟 ou 🛅	Workpiece classification with good or scrap as well
or using the rotary power control		as automatic printing if selected in the edition mode.

End of measure part N° 1 :

Indication of the part classification:



Symbol appearing if the part is within tolerance.

Symbol appearing if the part is rejected or needs to be reworked since at least one measured value is out of tolerance.



Once each workpiece has been measured, the following options are available:

To save the measured values in the relevant data file, close data file, return to first step for selecting another part programme or exit.

To view out-of-tolerance values



END

To cancel the measured workpiece



To erase last measured value



To save the measured values in data file and start probing another workpiece



 Δ^{v} or \overline{v} to list M and H values in their chronological order.

To print the measured values with header (hold key down to have this done)



GA

To prompt for the header you want to modify



To prompt for the statistics menu

END	SEAre	Choose another part programme or return to St-1/2
	Directoire programmes: DEMO01 DEMO05 DEMO02 DEMO06 DEMO03 DEMO07	
F1		Return to St-1/2
	△ M 4-M 2	



18.2) Programme with angle, perpendicularity and 2D measurements:

The way some specific measurements are carried out is described hereafter:

	Generating the capture of a new reference B	
Activating key according to set parameters in the edition mode	$\begin{bmatrix} M & M & M & M & M & M & M & M & M & M $	Display shows numbered value M 5 Response and waiting times are those previously entered in the configuration mode.
Enabling automatic probing sequence	× ال	Probing down is in progress. Displayed data depend on the type of measurement to be taken.
Activating key according to set parameters in the edition mode		Display shows numbered value M6 (reference B) Response and waiting times are those previously entered in the configuration mode.
	🛛 🕅 🖌 Palpage Bas 🛛 🔊 🗩	



	Carrying on with flatness measurement		
Activating key according to the previous dim ension parameters set in the edition mode	550225mm ~	, 	Access the measuring mode. Programme is waiting until first probe contact is started up.
	M8 Planéité 🖉		
or using	<u> </u>	,	Display shows floating value. V-sign indicates moving direction.
rotary power control	M8 Planéité	~	The rotary power control may also be used for for approaching the probing point.
		ţÇ	Contact the workpiece surface with the probe and start probing
	M8 Planéité	, ₩	Contact the workpiece surface with the probe and start probing once it has stabilised.
	M8 Planéité	, C , C	Contact the workpiece surface with the probe and start probing once it has stabilised.
	M8 Planéité	t€ ,	Contact the workpiece surface with the probe and start probing once it has stabilised. Main display shows instant value. V-sign indicates moving direction.
	M8 Planéité	• • • •	Contact the workpiece surface with the probe and start probing once it has stabilised. Main display shows instant value. V-sign indicates moving direction.



or or using		Main display shows numbered value M8. Auxiliary display shows next part feature to be probed.
the rotary power control	M9 Maximum 👘 😥 🗩 🖉	
Activating key according to the previous dimension parameters		Next step depends on the action you want to take, i.e: execute another measurement, measure
set in the edition mode	Start -2D	perpendicularity or flatness, perform a 2D measurement. In this example, display asks for a 2D measurement to be taken.
	Carrying on with angle measurement	
Activating key according to the previous dimension parameters set in the edition mode		Prompt for angle measurement using a gauge block
	P1 $P1$ $P1$ $P1$ $P1$ $P1$ $P1$ $P1$	Proceed step by step for all angle measurement.
	ſ₽	First probe contact
or using the rotary power control	P2 palpage bas	














Activating key according to the previous dimension parameters		Display shows angle value M10	
set in the edition mode	\triangleleft		
	M11 Rectitude		
Activating key according to the previous dimension		Display shows straightness value M11	
parameters set in the edition mode			
	Défaut de forme		
	Carrying on with 2D measurement		
Displaying positioning along with related probe contact		Usual configuration : Automatic displaying and positioning	
This sequence may be interrupted using the rotary power control.	Hy 1	based on both given response and waiting times.	
Displaying positioning along with related probe contact This sequence may be interrupted using the rotary	$ \begin{array}{c c} & A \\ \hline \bullet \\ \hline \bullet \\ \hline \bullet \\ \hline \end{array} \end{array} \\ \hline mm \end{array} $	Display shows probe position for value capture (H1).	
	T 70.1500		
power control	Hy 1		

N° ME07.99077



Displaying positioning along with related probe contact This sequence may be interrupted using the rotary power control		Displayed value once captured as soon as given response time went by go to the next step.
	t [*] Ø 45.0090 Hy 3 Ø	
Displaying positioning along with related probe contact		Display shows probe position for next value capture (H3)
This sequence may be interrupted using the rotary power control	T 87.1050 Hy 3	
Displaying positioning along with related probe contact This sequence may be interrupted using the rotary power control		Displayed value H3 once done. After response time is over, probe moves into position for
	₩ 24.9910 ₩ 4 Hy 6	next value capture (H6).
Displaying positioning along with related probe contact This sequence may be interrupted using the		Displayed value H6.
	[▶] Ø 15.0050	
rotary power control	Rot 🖾 🛛 🖉 🗩	





POWER PANEL plus M





POWER PANEL plus M



19) <u>Statistics menu</u>

This menu can be called out from either of the three following sequences:

- 1) Measuring mode
- 2) Execution mode
- 3) Managing data file menu















	Image: Construction of the second state of the second s	Auxiliary display shows processed values that relate to selected dimension.
	Prompting for histogram	
HIST	Image: Normal system Image: Normal system Image: Normal system 1 9.0% Image: Normal system Image: Normal system 2 8.2% Normal system Image: Normal system 0 0.0% Image: Normal system Image: Normal system 2 9.0% Image: Normal system Image: Normal system 1 9.0% Image: Normal system Image: Normal system	Displayed data related to M1 with: 8 good classes 2 out-of tolerance values Standard deviation (S) Cp= (upper T minus lower T) / 6S Cm= (upper T minus lower T) / 8S
	To enter header text Find the histogram of the selected dimension (M1 in this or or is to choose another dimension Image: Constant of the selected dimension Im	example)



	Prompting for Xbar card	
$\overline{\mathbf{X}}$	$\begin{bmatrix} n \\ m \\$	Displayed measuring process for M1. X scale always shows the last 25 samples of n workpieces.
	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	not within control limits are either marked with the arrow key ? or with ? pointed to the relevant limit value.
	or \sim : to choose another dimension or \sim : to display previous or next samples (25 items)	
\square	FERE.	Quit Xbar card
	Alésage Diamètre Cm 0.0000 Moy. 84.9040 Nb valeurs 12 Cmk 0.0000 Max. 84.9090 S 0.03600 -3S 0.0000 Min. 84.8605 % Bon 100% +3S 0.0000 Etendue 0.0485 HIST X X X X X	
	Return to the execution mode or in the managing files menu.	



20) Interfaces

This section describes the input sockets on the top and back of your control panel.



20.1) RS 232 digital input

This input allows the connection of an opto-electronic measuring instrument, RS type, which can be purchased from TESA or any other manufacturer. The following parameters can be altered as desired in the configuration menu:

Data rate:	
Character length:	
Start :	
Stop :	
Parity :	

4800 bauds 7 bits 1 bit 2 bits even

Transmission format : With use of the cable No. 04761049, bidirectional : as above or opto-RS With use of the cable No. 04761046, monodirectional : 4800 bauds (or 1200 bauds for a measuring instrument from an earlier generation), 7b, 2P, 2S, oh.



20.2) RS 232 digital output

The connecting cable 04761052 is used to link TESA Micro-hite *plus* M to SPC Printer or a host computer.

Data rate:	4800 bauds
Data bits:	7 bits
Start :	1 bit
Stop :	2 bits
Parity :	even

These parameters can be altered in the configuration mode.

Monodirectional or bidirectional data transfer

Data transfer may either be triggered off by activating the function key or using a remote control switch (hand or foot switch) connected to « EXT.P » at the rear of your control panel.

Data	mm :	±9999.999(9) <cr lf=""></cr>
transfer	ln :	±99.99999 <cr lf=""></cr>

Bidirectional data transfer

This transfer mode allows direct control of the height gauge from a PC. Given instructions are as below. Each order must be ended using ASCII code « CR ».

? <cr></cr>	Measured value	
ID ? <cr></cr>	Insrument's identification	TE… <cr lf=""></cr>
VER ? <cr></cr>	Instrument's version	2.1 <cr lf=""></cr>
UNI ? <cr></cr>	Unit system	MM or IN <cr lf=""></cr>
MM <cr></cr>	Metric (mm)	<cr lf=""></cr>
IN <cr></cr>	Inch (in)	<cr lf=""></cr>

Pin layout on the 9-pin (female) connector:

Control panel:		PC:
2 TXD (Data Out)	\rightarrow	RXD
3 RXD (Data Req)	←	TXD
5 GND		

Additional pins (unused):





20.3) CENTRONICS output and printer type (A4)

The Centronics output can accept any A4 printer type fitted with a parallel port.

Choice of drivers that can be used:

A) Epson LX 80B) HP PCL (HP Laser Jet 1200 series)

Paper length: From 9 to 13 inches. Standard length is 12 inches.

Use the configuration menu to select desired printer.

Note: As long as the printer buffer does not contained a full page, most of the Laser printer do not start to print. To print a <u>non completed page press</u>

the appropriate button on the printer of the key on the panel.



21 Printing formats

<u>SPC Printer</u> Perpendicularity curve

Part Nbr:.... Series Nbr:.... Part name:... Drawing Nbr:... Company:... Operator:...

Deviation from perpendicularity: X = 0.3460 mm: Z = 100.7285 mmHighest value: X1= 0.0000 mm: Z1= 0.0000 mmLowest value:

X2= -0.3460 mm : Z2= 99.9635 mm Deviation from straightness :RCT= 0.00283460 mm Sloping deviation: ANG= 0°05'26' deg

Graphical curve





<u>Centronics</u> Perpendicularity curve





22) Exporting data files to PC

A program used on a PC allows the transfer of program and data files from the column gauge into the PC and in the opposite way. By means of this program it is possible to load a language file into the column gauge.





22.1) <u>Data file format</u>

The format of the results file created on the PC is the following:

Number of measured value, described Parameters, Value, Nominal, Upper Tol., Lower Tol., Diff. (Deviation from nominal),

Date:2003/03/24 Time:17:43:09 Time:17:47:12 Date:2003/03/24 Part No: Serial No: Part name: Drawings No: Company: Operator: **BEGIN** 1 M001, "Radius d6 1:3", 52.4787, 52.4771, 0.0100, 0.0000, 0.0016 M002,"Angle d6 1:3",0.6539,0.6540,0.0100,0.0100,-0.0001 M003,"lg. totale: Centre X",9.6075,9.6000,0.0500,-0.0500,0.0075, M004,"lg. 6.8: Centre X",-6.7933,-6.8000,0.0500,-0.0500,0.0067, M005,"angle 0.08x45°: Angle XY",-45.664,-45.000,2.000,-2.000,-0.664, M006,"lg.0.50: Composante X",0.6159,0.5000,0.0500,-0.0500,0.1159,0.0659, M007,"Lg. 1.4: Composante X",1.4153,1.4000,0.0500,-0.0500,0.0153, M008, "Ø1.63: Composante Y", 1.6323, 1.6300, 0.0200, -0.0300, 0.0023, M009, "Ø1.83: Composante Y", 1.8262, 1.8300, 0.0300, -0.0300, -0.0038, M010,"Lg. 0.08: Composante X",0.0956,0.0800,0.0200,-0.0300,0.0156, M011,"lg. 2.40: Centre X",-2.4124,-2.4000,0.1000,-0.1000,-0.0124, M012,"largeur 0.27: Composante Y",0.2573,0.2700,0.0300,-0.0200,-0.0127, END

23) Sales programme

POWER PANEL <i>plus</i> M with built-in printer	TESA Order N°: 00760220
Pupitre POWER PANEL <i>plus</i> M without built-in printer	TESA Order N°: 00760221
Options :	
Thermal paper roll, 57 mm wide	TESA order N°: 04765008
Battery Back-up	TESA order N°: 031269



25) <u>Warranty</u>

We guarantee this product against any fault of design, manufacture or material for a period of 12 months from the date of purchase. any repair work carried out under the guarantee conditions is free of charge. Our responsibility is limited to the repair of the product or, if we consider it necessary, to its free replacement.

The following are not covered by our guarantee:

batteries and damages due to incorrect handling, failure to observe the instruction manual, or attempts by any non-qualified party to repair the product; any consequences whatever which may be connected either directly or indirectly with the prod-uct supplied or its use.

(Extract from our General Terms of Delivery, December 1, 1981)



26) <u>Declaration of conformity</u>

We thank you very much for your confidence in purchasing this product.

Declaration of conformity with confirmation of traceability

We declare under our sole responsibility that this product is in conformity with all technical data as specified in our sales literature (instruction manual, leaflet, general catalogue). In addition, we certify that the measuring equipment used to check this product refers to national reference standards.

Traceability of the measured values is ensured by our Quality Assurance.

Declaration of conformity with ISO/CEI Guide 22 as well as EN 45014

Manufacturer:

TESA S.A.

Full name and address:

TESA SA Rue du Bugnon 38 CH-1020 RENENS Switzerland

We declare that the following product(s):

Product name

Product type

TESA MICRO-HITE *plus* M Power Panel *plus* M 00730060 / 00730061 / 00730062 00730063 / 00730064 / 00730065 00760220 / 00760221

is (are) in compliance with the following standard (*): EN 61326-1, Classe B

* with unplugged battlery charger

Each product supplied conform with the European guidelines 73/23/CEE and 89/336/CEE, which were modified at a later date according to the guideline 93/68/CEE

Renens, 31st March 2003

@ Richard

J.D. Richard Manager of Quality Assurance